

PMDG 777 CUSTOM EVENT ID's

for use with FSUIPC and FSX, FSX-SE or Prepar3D*

SP1c Cockpit Builder Edition



is a free service of

www.myhomecockpit.de

www.flightm.com

©2015 Flight! Magazin - A.Giel

Overhead - Hydraulic	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_HYD_DEMAND_ELEC1	35	69667			
EVT_OH_HYD_AIR1	36	69668			
EVT_OH_HYD_AIR2	37	69669			
EVT_OH_HYD_DEMAND_ELEC2	38	69670			
EVT_OH_HYD_ENG1	39	69671			
EVT_OH_HYD_ELEC1	40	69672			
EVT_OH_HYD_ELEC2	41	69673			
EVT_OH_HYD_ENG2	42	69674			
EVT_OH_HYD_RAM_AIR	43	69675			
EVT_OH_HYD_RAM_AIR_COVER	44	69676			

Overhead - Electric	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_ELEC_BATTERY_SWITCH	1	69633			
EVT_OH_ELEC_APU_GEN_SWITCH	2	69634			
EVT_OH_ELEC_APU_SEL_SWITCH	3	69635			
EVT_OH_ELEC_BUS_TIE1_SWITCH	5	69637			
EVT_OH_ELEC_BUS_TIE2_SWITCH	6	69638			
EVT_OH_ELEC_GRD_PWR_SEC_SWITCH	7	69639			
EVT_OH_ELEC_GRD_PWR_PRIM_SWITCH	8	69640			
EVT_OH_ELEC_GEN1_SWITCH	9	69641			
EVT_OH_ELEC_GEN2_SWITCH	10	69642			
EVT_OH_ELEC_BACKUP_GEN1_SWITCH	11	69643			
EVT_OH_ELEC_BACKUP_GEN2_SWITCH	12	69644			
EVT_OH_ELEC_DISCONNECT1_SWITCH	13	69645			
EVT_OH_ELEC_DISCONNECT1_GUARD	14	69646			
EVT_OH_ELEC_DISCONNECT2_SWITCH	15	69647			
EVT_OH_ELEC_DISCONNECT2_GUARD	16	69648			
EVT_OH_ELEC_IFE	17	69649			
EVT_OH_ELEC_CAB_UTIL	18	69650			
EVT_OH_ELEC_STBY_PWR_SWITCH	81	69713			
EVT_OH_ELEC_STBY_PWR_GUARD	82	69714			
EVT_OH_ELEC_TOWING_PWR_SWITCH	150	69782			
EVT_OH_ELEC_TOWING_PWR_GUARD	151	69783			
EVT_OH_ELEC_GND_TEST_SWITCH	152	69784			
EVT_OH_ELEC_GND_TEST_GUARD	153	69785			

Overhead - FUEL Panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_FUEL_JETTISON_NOZZLE_L	97	69729			
EVT_OH_FUEL_JETTISON_NOZZLE_L_GUARD	98	69730			
EVT_OH_FUEL_JETTISON_NOZZLE_R	99	69731			
EVT_OH_FUEL_JETTISON_NOZZLE_R_GUARD	100	69732			
EVT_OH_FUEL_TO_REMAIN_ROTATE	101	69733			
EVT_OH_FUEL_TO_REMAIN_PULL	10100	79732			
EVT_OH_FUEL_JETTISON_ARM	102	69734			
EVT_OH_FUEL_PUMP_1_FORWARD	103	69735			
EVT_OH_FUEL_PUMP_2_FORWARD	104	69736			
EVT_OH_FUEL_PUMP_1_AFT	105	69737			
EVT_OH_FUEL_PUMP_2_AFT	106	69738			
EVT_OH_FUEL_CROSSFEED_FORWARD	107	69739			

EVT_OH_FUEL_CROSSFEED_AFT	108	69740			
EVT_OH_FUEL_PUMP_L_CENTER	109	69741			
EVT_OH_FUEL_PUMP_R_CENTER	110	69742			
EVT_OH_FUEL_PUMP_AUX	1037	70669			

Overhead Air	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_BLEED_ENG_1_SWITCH	129	69761			
EVT_OH_BLEED_ENG_2_SWITCH	130	69762			
EVT_OH_BLEED_APU_SWITCH	131	69763			
EVT_OH_BLEED_ISOLATION_VALVE_SWITCH_L	132	69764			
EVT_OH_BLEED_ISOLATION_VALVE_SWITCH_C	133	69765			
EVT_OH_BLEED_ISOLATION_VALVE_SWITCH_R	134	69766			
EVT_OH_AIRCOND_PACK_SWITCH_L	135	69767			
EVT_OH_AIRCOND_PACK_SWITCH_R	136	69768			
EVT_OH_AIRCOND_TRIM_AIR_SWITCH_L	137	69769			
EVT_OH_AIRCOND_TRIM_AIR_SWITCH_R	138	69770			
EVT_OH_AIRCOND_TEMP_SELECTOR_FLT_DECK	139	69771			
EVT_OH_AIRCOND_TEMP_SELECTOR_CABIN	140	69772			
EVT_OH_AIRCOND_RESET_SWITCH	141	69773			
EVT_OH_AIRCOND_RECIRC_FAN_UPP_SWITCH	142	69774			
EVT_OH_AIRCOND_RECIRC_FAN_LWR_SWITCH	143	69775			
EVT_OH_AIRCOND_EQUIP_COOLING_SWITCH	144	69776			
EVT_OH_AIRCOND_GASPER_SWITCH	145	69777			
EVT_OH_AIRCOND_TEMP_SELECTOR_CARGO_AFT	148	69780			
EVT_OH_AIRCOND_TEMP_SELECTOR_CARGO_BULK	149	69781			
EVT_OH_AIRCOND_TEMP_SELECTOR_LWR_CARGO_FWD	1050	70682			
EVT_OH_AIRCOND_TEMP_SELECTOR_LWR_CARGO_AFT	1051	70683			
EVT_OH_AIRCOND_RECIRC_FANS_SWITCH	1052	70684			
EVT_OH_AIRCOND_TEMP_SELECTOR_MAIN_CARGO_FWD	1054	70686			
EVT_OH_AIRCOND_TEMP_SELECTOR_MAIN_CARGO_AFT	1055	70687			
EVT_OH_AIRCOND_MAIN_DECK_FLOW_SWITCH	1053	70685			
EVT_OH_AIRCOND_ALT_VENT_SWITCH	1057	70689			
EVT_OH_AIRCOND_ALT_VENT_GUARD	1111	70743			

Overhead - Cabin Press	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_PRESS_VALVE_SWITCH_MANUAL_1	124	69756			
EVT_OH_PRESS_VALVE_SWITCH_MANUAL_2	125	69757			
EVT_OH_PRESS_LAND_ALT_KNOB_ROTATE	126	69758			
EVT_OH_PRESS_LAND_ALT_KNOB_PULL	12600	82232			
EVT_OH_PRESS_VALVE_SWITCH_1	127	69759			
EVT_OH_PRESS_VALVE_SWITCH_2	128	69760			

Overhead - ANTI-ICE	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_ICE_WINDOW_HEAT_1	45	69677			
EVT_OH_ICE_WINDOW_HEAT_2	46	69678			
EVT_OH_ICE_WINDOW_HEAT_3	47	69679			
EVT_OH_ICE_WINDOW_HEAT_4	48	69680			
EVT_OH_ICE_BU_WINDOW_HEAT_L	77	69709			
EVT_OH_ICE_BU_WINDOW_HEAT_L_GUARD	78	69710			
EVT_OH_ICE_BU_WINDOW_HEAT_R	79	69711			

EVT_OH_ICE_BU_WINDOW_HEAT_R_GUARD	80	69712			
EVT_OH_ICE_WING_ANTIICE	111	69743			
EVT_OH_ICE_ENGINE_ANTIICE_1	112	69744			
EVT_OH_ICE_ENGINE_ANTIICE_2	113	69745			

Overhead Lights Panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_LIGHTS_LANDING_L	22	69654			
EVT_OH_LIGHTS_LANDING_NOSE	23	69655			
EVT_OH_LIGHTS_LANDING_R	24	69656			
EVT_OH_LIGHTS_STORM	27	69659			
EVT_OH_LIGHTS_BEACON	114	69746			
EVT_OH_LIGHTS_NAV	115	69747			
EVT_OH_LIGHTS_LOGO	116	69748			
EVT_OH_LIGHTS_WING	117	69749			
EVT_OH_LIGHTS_IND_LTS_SWITCH	118	69750			
EVT_OH_LIGHTS_L_TURNOFF	119	69751			
EVT_OH_LIGHTS_R_TURNOFF	120	69752			
EVT_OH_LIGHTS_TAXI	121	69753			
EVT_OH_LIGHTS_STROBE	122	69754			
EVT_OH_NO_SMOKING_LIGHT_SWITCH	29	69661			
EVT_OH_FASTEN_BELTS_LIGHT_SWITCH	30	69662			
EVT_OH_PANEL_LIGHT_CONTROL	25	69657			
EVT_OH_CB_LIGHT_CONTROL	2501	72133			
EVT_OH_GS_PANEL_LIGHT_CONTROL	21	69653			
EVT_OH_GS_FLOOD_LIGHT_CONTROL	2101	71733			
EVT_OH_DOME_SWITCH	26	69658			
EVT_OH_MASTER_BRIGHT_ROTATE	28	69660			
EVT_OH_MASTER_BRIGHT_PUSH	2801	72433			

Overhead - APU & Cargo Fire Panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_FIRE_CARGO_ARM_FWD	85	69717			
EVT_OH_FIRE_CARGO_ARM_AFT	86	69718			
EVT_OH_FIRE_CARGO_DISCH	87	69719			
EVT_OH_FIRE_CARGO_DISCH_GUARD	88	69720			
EVT_OH_FIRE_OVHT_TEST	89	69721			
EVT_OH_FIRE_HANDLE_APU_TOP	84	69716			
EVT_OH_FIRE_HANDLE_APU_BOTTOM	8401	78033			
EVT_OH_FIRE_UNLOCK_SWITCH_APU	8402	78034			
EVT_OH_FIRE_CARGO_ARM_MAIN_DECK	1074	70706			
EVT_OH_FIRE_CARGO_DISCH_DEPR	1075	70707			

Overhead - Engine control	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_EEC_L_SWITCH	90	69722			
EVT_OH_EEC_L_GUARD	91	69723			
EVT_OH_EEC_R_SWITCH	92	69724			
EVT_OH_EEC_R_GUARD	93	69725			
EVT_OH_ENGINE_L_START	94	69726			
EVT_OH_ENGINE_R_START	95	69727			
EVT_OH_ENGINE_AUTOSTART	96	69728			

Overhead - Miscellaneous	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OH_CAMERA_LTS_SWITCH	19	69651			
EVT_OH_WIPER_LEFT_SWITCH	20	69652			
EVT_OH_EMER_EXIT_LIGHT_SWITCH	49	69681			
EVT_OH_EMER_EXIT_LIGHT_GUARD	50	69682			
EVT_OH_SERVICE_INTERPHONE_SWITCH	51	69683			
EVT_OH_OXY_PASS_SWITCH	52	69684			
EVT_OH_OXY_PASS_GUARD	53	69685			
EVT_OH_OXY_SUPRNMRY_SWITCH	1076	70708			
EVT_OH_OXY_SUPRNMRY_GUARD	1077	70709			
EVT_OH_THRUST_ASYM_COMP	54	69686			
EVT_OH_PRIM_FLT_COMPUTERS	55	69687			
EVT_OH_PRIM_FLT_COMPUTERS_GUARD	56	69688			
EVT_OH_ADIRU_SWITCH	59	69691			
EVT_OH_HYD_VLV_PWR_WING_L	60	69692			
EVT_OH_HYD_VLV_PWR_WING_L_GUARD	61	69693			
EVT_OH_HYD_VLV_PWR_WING_C	63	69695			
EVT_OH_HYD_VLV_PWR_WING_C_GUARD	64	69696			
VT_OH_HYD_VLV_PWR_WING_R	66	69698			
EVT_OH_HYD_VLV_PWR_WING_R_GUARD	67	69699			
EVT_OH_HYD_VLV_PWR_TAIL_L	69	69701			
EVT_OH_HYD_VLV_PWR_TAIL_L_GUARD	70	69702			
EVT_OH_HYD_VLV_PWR_TAIL_C	71	69703			
EVT_OH_HYD_VLV_PWR_TAIL_C_GUARD	72	69704			
EVT_OH_HYD_VLV_PWR_TAIL_R	74	69706			
EVT_OH_HYD_VLV_PWR_TAIL_R_GUARD	75	69707			
EVT_OH_WIPER_RIGHT_SWITCH 1	123	69755			
EVT_OH_CVR_TEST	156	69788			
EVT_OH_CVR_ERASE	157	69789			
EVT_OH_APU_TEST_SWITCH	159	69791			
EVT_OH_APU_TEST_SWITCH_GUARD	160	69792			
EVT_OH_EEC_TEST_L_SWITCH	161	69793			
EVT_OH_EEC_TEST_L_SWITCH_GUARD	162	69794			
EVT_OH_EEC_TEST_R_SWITCH	163	69795			
EVT_OH_EEC_TEST_R_SWITCH_GUARD	164	69796			
EVT_GPWS_RWY_OVRD_SWITCH	1109	70741			
EVT_GPWS_RWY_OVRD_GUARD	1110	70742			

Forward Panel - Instrument Source Select	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_FWD_NAV_SOURCE_L	168	69800			
EVT_FWD_DSPL_CTRL_SOURCE_L	169	69801			
EVT_FWD_AIR_DATA_ATT_SOURCE_L	170	69802			
EVT_FWD_NAV_SOURCE_R	276	69908			
EVT_FWD_DSPL_CTRL_SOURCE_R	277	69909			
EVT_FWD_AIR_DATA_ATT_SOURCE_R	278	69910			
EVT_FWD_FMC_SELECTOR	291	69923			

Forward Panel - Display Selectors	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_DSP_INDB_DSPL_L	315	69947			
EVT_DSP_INDB_DSPL_R	290	69922			

Forward Panel - Heading Reference	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_EFIS_HDG_REF_SWITCH	313	69945			
EVT_EFIS_HDG_REF_GUARD	314	69946			

Forward Panel - Gear	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_GEAR_LEVER	295	69927			
EVT_GEAR_LEVER_UNLOCK	296	69928			
EVT_GEAR_ALTN_GEAR_DOWN	293	69925			
EVT_GEAR_ALTN_GEAR_DOWN_GUARD	294	69926			

Forward Panel - GPWS	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_GPWS_TERR_OVRD_SWITCH	297	69929			
EVT_GPWS_TERR_OVRD_GUARD	298	69930			
EVT_GPWS_GEAR_OVRD_SWITCH	299	69931			
EVT_GPWS_GEAR_OVRD_GUARD	300	69932			
EVT_GPWS_FLAP_OVRD_SWITCH	301	69933			
EVT_GPWS_FLAP_OVRD_GUARD	302	69934			
EVT_GPWS_GS_INHIBIT_SWITCH	303	69935			

Forward Panel - Autobrakes	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_ABS_AUTOBRAKE_SELECTOR	292	69924			

Forward Panel - ISFD	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_ISFD_APP	810	70442			
EVT_ISFD_HP_IN	811	70443			
EVT_ISFD_PLUS	812	70444			
EVT_ISFD_MINUS	813	70445			
EVT_ISFD_ATT_RST	814	70446			
EVT_ISFD_BARO	815	70447			
EVT_ISFD_BARO_PUSH	816	70448			

Forward Panel - non-ISFD standby instruments	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_STANDBY_ASI_KNOB	1058	70690			
EVT_STANDBY_ASI_KNOB_PUSH	1059	70691			
EVT_STANDBY_ALTIMETER_KNOB	1060	70692			
EVT_STANDBY_ALTIMETER_KNOB_PUSH	1061	70693			

Forward Panel - Chronometers	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_CHRONO_L_CHR	171	69803			
EVT_CHRONO_L_TIME_DATE_SELECT	172	69804			
EVT_CHRONO_L_TIME_DATE_PUSH	1721	71353			
EVT_CHRONO_L_ET	173	69805			
EVT_CHRONO_L_SET	174	69806			
EVT_CHRONO_R_CHR	279	69911			
EVT_CHRONO_R_TIME_DATE_SELECT	280	69912			
EVT_CHRONO_R_TIME_DATE_PUSH	2802	72434			
EVT_CHRONO_R_ET	281	69913			
EVT_CHRONO_R_SET	282	69914			

Forward Panel - Left Sidewall	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_FWD_LEFT_SHOULDER_HEATER	318	69950			
EVT_FWD_LEFT_FOOT_HEATER	319	69951			
EVT_FWD_LEFT_OUTBD_BRIGHT_CONTROL	320	69952			
EVT_FWD_LEFT_INBD_BRIGHT_CONTROL	321	69953			
EVT_FWD_LEFT_INBD_TERR_BRIGHT_CONTROL	3210	72842			
EVT_FWD_LEFT_PANEL_LIGHT_CONTROL	322	69954			
EVT_FWD_LEFT_FLOOD_LIGHT_CONTROL	3220	72852			

Forward Panel - Right Sidewall	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_FWD_RIGHT_FOOT_HEATER	288	69920			
EVT_FWD_RIGHT_SHOULDER_HEATER	289	69921			
EVT_FWD_RIGHT_PANEL_LIGHT_CONTROL	285	69917			
EVT_FWD_RIGHT_FLOOD_LIGHT_CONTROL	2850	72482			
EVT_FWD_RIGHT_INBD_BRIGHT_CONTROL	286	69918			
EVT_FWD_RIGHT_INBD_TERR_BRIGHT_CONTROL	2860	72492			
EVT_FWD_RIGHT_OUTBD_BRIGHT_CONTROL	287	69919			

Glareshield - EFIS Captain control panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_EFIS_CPT_MINIMUMS_RADIO_BARO	181	69813			
EVT_EFIS_CPT_MINIMUMS	182	69814			
EVT_EFIS_CPT_MINIMUMS_RST	183	69815			
EVT_EFIS_CPT_VOR_ADF_SELECTOR_L	184	69816			
EVT_EFIS_CPT_MODE	185	69817			
EVT_EFIS_CPT_MODE_CTR	186	69818			
EVT_EFIS_CPT_RANGE	187	69819			
EVT_EFIS_CPT_RANGE_TFC	188	69820			
EVT_EFIS_CPT_VOR_ADF_SELECTOR_R	189	69821			
EVT_EFIS_CPT_BARO_IN_HPA	190	69822			
EVT_EFIS_CPT_BARO	191	69823			
EVT_EFIS_CPT_BARO_STD	192	69824			
EVT_EFIS_CPT_FPV	193	69825			
EVT_EFIS_CPT_MTRS	194	69826			
EVT_EFIS_CPT_WXR	195	69827			
EVT_EFIS_CPT_STA	196	69828			
EVT_EFIS_CPT_WPT	197	69829			
EVT_EFIS_CPT_ARPT	198	69830			
EVT_EFIS_CPT_DATA	199	69831			
EVT_EFIS_CPT_POS	200	69832			
EVT_EFIS_CPT_TERR	201	69833			

Glareshield - EFIS FO control panels	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_EFIS_FO_MINIMUMS_RADIO_BARO	248	69880			
EVT_EFIS_FO_MINIMUMS	249	69881			
EVT_EFIS_FO_MINIMUMS_RST	250	69882			
EVT_EFIS_FO_VOR_ADF_SELECTOR_L	251	69883			
EVT_EFIS_FO_MODE	252	69884			
EVT_EFIS_FO_MODE_CTR	253	69885			
EVT_EFIS_FO_RANGE	254	69886			
EVT_EFIS_FO_RANGE_TFC	255	69887			

EVT_EFIS_FO_VOR_ADF_SELECTOR_R	256	69888			
EVT_EFIS_FO_BARO_IN_HPA	257	69889			
EVT_EFIS_FO_BARO	258	69890			
EVT_EFIS_FO_BARO_STD	259	69891			
EVT_EFIS_FO_FPV	260	69892			
EVT_EFIS_FO_MTRS	261	69893			
EVT_EFIS_FO_WXR	262	69894			
EVT_EFIS_FO_STA	263	69895			
EVT_EFIS_FO_WPT	264	69896			
EVT_EFIS_FO_ARPT	265	69897			
EVT_EFIS_FO_DATA	266	69898			
EVT_EFIS_FO_POS	267	69899			
EVT_EFIS_FO_TERR	268	69900			

Glareshield - MCP	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_MCP_FD_SWITCH_L	202	69834			
EVT_MCP_AP_L_SWITCH	203	69835			
EVT_MCP_AT_ARM_SWITCH_L	204	69836			
EVT_MCP_AT_ARM_SWITCH_R	205	69837			
EVT_MCP_CLB_CON_SWITCH	206	69838			
EVT_MCP_AT_SWITCH	207	69839			
EVT_MCP_IAS_MACH_SWITCH	208	69840			
EVT_MCP_SPEED_SELECTOR	210	69842			
EVT_MCP_SPEED_PUSH_SWITCH	2100	71732			
EVT_MCP_LNAV_SWITCH	211	69843			
EVT_MCP_VNAV_SWITCH	212	69844			
EVT_MCP_LVL_CHG_SWITCH	213	69845			
EVT_MCP_DISENGAGE_BAR	214	69846			
EVT_MCP_HDG_TRK_SWITCH	216	69848			
EVT_MCP_HEADING_PUSH_SWITCH	218	69850			
EVT_MCP_HEADING_SELECTOR	2180	71812			
EVT_MCP_BANK_ANGLE_SELECTOR	2181	71813			
EVT_MCP_HDG_HOLD_SWITCH	219	69851			
EVT_MCP_VS_FPA_SWITCH	220	69852			
EVT_MCP_VS_SELECTOR	222	69854			
EVT_MCP_VS_SWITCH	223	69855			
EVT_MCP_ALTITUDE_SELECTOR	2250	71882			
EVT_MCP_ALTITUDE_PUSH_SWITCH	2251	71883			
EVT_MCP_ALT_INCR_SELECTOR	225	69857			
EVT_MCP_ALT_HOLD_SWITCH	226	69858			
EVT_MCP_LOC_SWITCH	227	69859			
EVT_MCP_APP_SWITCH	228	69860			
EVT_MCP_AP_R_SWITCH	229	69861			
EVT_MCP_FD_SWITCH_R	230	69862			
EVT_MCP_TOGA_SCREW_L	5001	74633			
EVT_MCP_TOGA_SCREW_R	5002	74634			

Glareshield - Display Select Panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_DSP_L_INBD_SWITCH	231	69863			
EVT_DSP_R_INBD_SWITCH	232	69864			

EVT_DSP_LWR_CTR_SWITCH	233	69865			
EVT_DSP_ENG_SWITCH	234	69866			
EVT_DSP_STAT_SWITCH	235	69867			
EVT_DSP_ELEC_SWITCH	236	69868			
EVT_DSP_HYD_SWITCH	237	69869			
EVT_DSP_FUEL_SWITCH	238	69870			
EVT_DSP_AIR_SWITCH	239	69871			
EVT_DSP_DOOR_SWITCH	240	69872			
EVT_DSP_GEAR_SWITCH	241	69873			
EVT_DSP_FCTL_SWITCH	242	69874			
EVT_DSP_CAM_SWITCH	243	69875			
EVT_DSP_CHKL_SWITCH	244	69876			
EVT_DSP_COMM_SWITCH	245	69877			
EVT_DSP_NAV_SWITCH	246	69878			
EVT_DSP_CANC_RCL_SWITCH	247	69879			

Glareshield - Master Warning/caution	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_MASTER_WARNING_RESET_LEFT	177	69809			
EVT_MASTER_WARNING_RESET_RIGHT	272	69904			

Glareshield - Data Link Switches	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_DATA_LINK_ACPT_LEFT	178	69810			
EVT_DATA_LINK_CANC_LEFT	179	69811			
EVT_DATA_LINK_RJCT_LEFT	180	69812			
EVT_DATA_LINK_ACPT_RIGHT	269	69901			
EVT_DATA_LINK_CANC_RIGHT	270	69902			
EVT_DATA_LINK_RJCT_RIGHT	271	69903			

Glareshield - Miscellaneous	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_CLOCK_L	165	69797			
EVT_MAP_LIGHT_L	166	69798			
EVT_GLARESHIELD_MIC_L	167	69799			
EVT_GLARESHIELD_MIC_R	273	69905			
EVT_MAP_LIGHT_R	274	69906			
EVT_CLOCK_R	275	69907			
EVT_CHART_LIGHT_L	1107	70739			
EVT_CHART_LIGHT_R	1108	70740			
EVT_WORKTABLE_LIGHT_R	1105	70737			
EVT_WORKTABLE_LIGHT_L	1106	70738			

Pedestal - Fwd Aisle Stand - CDUs	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_CDU_L_L1	328	69960			
EVT_CDU_L_L2	329	69961			
EVT_CDU_L_L3	330	69962			
EVT_CDU_L_L4	331	69963			
EVT_CDU_L_L5	332	69964			
EVT_CDU_L_L6	333	69965			
EVT_CDU_L_R1	334	69966			
EVT_CDU_L_R2	335	69967			
EVT_CDU_L_R3	336	69968			

EVT_CDU_L_R4	337	69969			
EVT_CDU_L_R5	338	69970			
EVT_CDU_L_R6	339	69971			
EVT_CDU_L_INIT_REF	340	69972			
EVT_CDU_L_RTE	341	69973			
EVT_CDU_L_DEP_ARR	342	69974			
EVT_CDU_L_ALTN	343	69975			
EVT_CDU_L_VNAV	344	69976			
EVT_CDU_L_FIX	345	69977			
EVT_CDU_L_LEGS	346	69978			
EVT_CDU_L_HOLD	347	69979			
EVT_CDU_L_FMCCOMM	3471	73103			
EVT_CDU_L_PROG	348	69980			
EVT_CDU_L_EXEC	349	69981			
EVT_CDU_L_MENU	350	69982			
EVT_CDU_L_NAV_RAD	351	69983			
EVT_CDU_L_PREV_PAGE	352	69984			
EVT_CDU_L_NEXT_PAGE	353	69985			
EVT_CDU_L_1	354	69986			
EVT_CDU_L_2	355	69987			
EVT_CDU_L_3	356	69988			
EVT_CDU_L_4	357	69989			
EVT_CDU_L_5	358	69990			
EVT_CDU_L_6	359	69991			
EVT_CDU_L_7	360	69992			
EVT_CDU_L_8	361	69993			
EVT_CDU_L_9	362	69994			
EVT_CDU_L_DOT	363	69995			
EVT_CDU_L_0	364	69996			
EVT_CDU_L_PLUS_MINUS	365	69997			
EVT_CDU_L_A	366	69998			
EVT_CDU_L_B	367	69999			
EVT_CDU_L_C	368	70000			
EVT_CDU_L_D	369	70001			
EVT_CDU_L_E	370	70002			
EVT_CDU_L_F	371	70003			
EVT_CDU_L_G	372	70004			
EVT_CDU_L_H	373	70005			
EVT_CDU_L_I	374	70006			
EVT_CDU_L_J	375	70007			
EVT_CDU_L_K	376	70008			
EVT_CDU_L_L	377	70009			
EVT_CDU_L_M	378	70010			
EVT_CDU_L_N	379	70011			
EVT_CDU_L_O	380	70012			
EVT_CDU_L_P	381	70013			
EVT_CDU_L_Q	382	70014			
EVT_CDU_L_R	383	70015			
EVT_CDU_L_S	384	70016			
EVT_CDU_L_T	385	70017			

EVT_CDU_L_U	386	70018			
EVT_CDU_L_V	387	70019			
EVT_CDU_L_W	388	70020			
EVT_CDU_L_X	389	70021			
EVT_CDU_L_Y	390	70022			
EVT_CDU_L_Z	391	70023			
EVT_CDU_L_SPACE	392	70024			
EVT_CDU_L_DEL	393	70025			
EVT_CDU_L_SLASH	394	70026			
EVT_CDU_L_CLR	395	70027			
EVT_CDU_L_BRITENESS	400	70032			
EVT_CDU_R_L1	401	70033			
EVT_CDU_R_L2	402	70034			
EVT_CDU_R_L3	403	70035			
EVT_CDU_R_L4	404	70036			
EVT_CDU_R_L5	405	70037			
EVT_CDU_R_L6	406	70038			
EVT_CDU_R_R1	407	70039			
EVT_CDU_R_R2	408	70040			
EVT_CDU_R_R3	409	70041			
EVT_CDU_R_R4	410	70042			
EVT_CDU_R_R5	411	70043			
EVT_CDU_R_R6	412	70044			
EVT_CDU_R_INIT_REF	413	70045			
EVT_CDU_R_RTE	414	70046			
EVT_CDU_R_DEP_ARR	415	70047			
EVT_CDU_R_ALTN	416	70048			
EVT_CDU_R_VNAV	417	70049			
EVT_CDU_R_FIX	418	70050			
EVT_CDU_R_LEGS	419	70051			
EVT_CDU_R_HOLD	420	70052			
EVT_CDU_R_FMCCOMM	4201	73833			
EVT_CDU_R_PROG	421	70053			
EVT_CDU_R_EXEC	422	70054			
EVT_CDU_R_MENU	423	70055			
EVT_CDU_R_NAV_RAD	424	70056			
EVT_CDU_R_PREV_PAGE	425	70057			
EVT_CDU_R_NEXT_PAGE	426	70058			
EVT_CDU_R_1	427	70059			
EVT_CDU_R_2	428	70060			
EVT_CDU_R_3	429	70061			
EVT_CDU_R_4	430	70062			
EVT_CDU_R_5	431	70063			
EVT_CDU_R_6	432	70064			
EVT_CDU_R_7	433	70065			
EVT_CDU_R_8	434	70066			
EVT_CDU_R_9	435	70067			
EVT_CDU_R_DOT	436	70068			
EVT_CDU_R_0	437	70069			
EVT_CDU_R_PLUS_MINUS	438	70070			

EVT_CDU_R_A	439	70071			
EVT_CDU_R_B	440	70072			
EVT_CDU_R_C	441	70073			
EVT_CDU_R_D	442	70074			
EVT_CDU_R_E	443	70075			
EVT_CDU_R_F	444	70076			
EVT_CDU_R_G	445	70077			
EVT_CDU_R_H	446	70078			
EVT_CDU_R_I	447	70079			
EVT_CDU_R_J	448	70080			
EVT_CDU_R_K	449	70081			
EVT_CDU_R_L	450	70082			
EVT_CDU_R_M	451	70083			
EVT_CDU_R_N	452	70084			
EVT_CDU_R_O	453	70085			
EVT_CDU_R_P	454	70086			
EVT_CDU_R_Q	455	70087			
EVT_CDU_R_R	456	70088			
EVT_CDU_R_S	457	70089			
EVT_CDU_R_T	458	70090			
EVT_CDU_R_U	459	70091			
EVT_CDU_R_V	460	70092			
EVT_CDU_R_W	461	70093			
EVT_CDU_R_X	462	70094			
EVT_CDU_R_Y	463	70095			
EVT_CDU_R_Z	464	70096			
EVT_CDU_R_SPACE	465	70097			
EVT_CDU_R_DEL	466	70098			
EVT_CDU_R_SLASH	467	70099			
EVT_CDU_R_CLR	468	70100			
EVT_CDU_R_BRITENESS	469	70101			
EVT_CDU_C_L1	653	70285			
EVT_CDU_C_L2	654	70286			
EVT_CDU_C_L3	655	70287			
EVT_CDU_C_L4	656	70288			
EVT_CDU_C_L5	657	70289			
EVT_CDU_C_L6	658	70290			
EVT_CDU_C_R1	659	70291			
EVT_CDU_C_R2	660	70292			
EVT_CDU_C_R3	661	70293			
EVT_CDU_C_R4	662	70294			
EVT_CDU_C_R5	663	70295			
EVT_CDU_C_R6	664	70296			
EVT_CDU_C_INIT_REF	665	70297			
EVT_CDU_C_RTE	666	70298			
EVT_CDU_C_DEP_ARR	667	70299			
EVT_CDU_C_ALTN	668	70300			
EVT_CDU_C_VNAV	669	70301			
EVT_CDU_C_FIX	670	70302			
EVT_CDU_C_LEGS	671	70303			

EVT_CDU_C_HOLD	672	70304		
EVT_CDU_C_FMCCOMM	6721	76353		
EVT_CDU_C_PROG	673	70305		
EVT_CDU_C_EXEC	674	70306		
EVT_CDU_C_MENU	675	70307		
EVT_CDU_C_NAV_RAD	676	70308		
EVT_CDU_C_PREV_PAGE	677	70309		
EVT_CDU_C_NEXT_PAGE	678	70310		
EVT_CDU_C_1	679	70311		
EVT_CDU_C_2	680	70312		
EVT_CDU_C_3	681	70313		
EVT_CDU_C_4	682	70314		
EVT_CDU_C_5	683	70315		
EVT_CDU_C_6	684	70316		
EVT_CDU_C_7	685	70317		
EVT_CDU_C_8	686	70318		
EVT_CDU_C_9	687	70319		
EVT_CDU_C_DOT	688	70320		
EVT_CDU_C_0	689	70321		
EVT_CDU_C_PLUS_MINUS	690	70322		
EVT_CDU_C_A	691	70323		
EVT_CDU_C_B	692	70324		
EVT_CDU_C_C	693	70325		
EVT_CDU_C_D	694	70326		
EVT_CDU_C_E	695	70327		
EVT_CDU_C_F	696	70328		
EVT_CDU_C_G	697	70329		
EVT_CDU_C_H	698	70330		
EVT_CDU_C_I	699	70331		
EVT_CDU_C_J	700	70332		
EVT_CDU_C_K	701	70333		
EVT_CDU_C_L	702	70334		
EVT_CDU_C_M	703	70335		
EVT_CDU_C_N	704	70336		
EVT_CDU_C_O	705	70337		
EVT_CDU_C_P	706	70338		
EVT_CDU_C_Q	707	70339		
EVT_CDU_C_R	708	70340		
EVT_CDU_C_S	709	70341		
EVT_CDU_C_T	710	70342		
EVT_CDU_C_U	711	70343		
EVT_CDU_C_V	712	70344		
EVT_CDU_C_W	713	70345		
EVT_CDU_C_X	714	70346		
EVT_CDU_C_Y	715	70347		
EVT_CDU_C_Z	716	70348		
EVT_CDU_C_SPACE	717	70349		
EVT_CDU_C_DEL	718	70350		
EVT_CDU_C_SLASH	719	70351		
EVT_CDU_C_CLR	720	70352		

EVT_CDU_C_BRITENESS	721	70353			
---------------------	-----	-------	--	--	--

Pedestal - Fwd Aisle Stand	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_PED_DSPL_CTRL_SOURCE_C	478	70110			
EVT_PED_EICAS_EVENT_RCD	479	70111			
EVT_PED_UPPER_BRIGHT_CONTROL	480	70112			
EVT_PED_LOWER_BRIGHT_CONTROL	481	70113			
EVT_PED_LOWER_TERR_BRIGHT_CONTROL	4811	74443			
EVT_PED_L_CCD_SIDE	482	70114			
EVT_PED_L_CCD_INBD	483	70115			
EVT_PED_L_CCD_LWR	484	70116			
EVT_PED_R_CCD_LWR	489	70121			
EVT_PED_R_CCD_INBD	490	70122			
EVT_PED_R_CCD_SIDE	491	70123			

Pedestal - Control Stand - Fire protection panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_FIRE_HANDLE_ENGINE_1_TOP	651	70283			
EVT_FIRE_HANDLE_ENGINE_1_BOTTOM	6511	76143			
EVT_FIRE_HANDLE_ENGINE_2_TOP	652	70284			
EVT_FIRE_HANDLE_ENGINE_2_BOTTOM	6521	76153			
EVT_FIRE_UNLOCK_SWITCH_ENGINE_1	6512	76144			
EVT_FIRE_UNLOCK_SWITCH_ENGINE_2	6522	76154			

Pedestal - Control Stand - Flaps	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_ALTN_FLAPS_ARM	510	70142			
EVT_ALTN_FLAPS_ARM_GUARD	511	70143			
EVT_ALTN_FLAPS_POS	512	70144			

Pedestal - Control Stand - Fuel Control	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_CONTROL_STAND_ENG1_START_LEVER	520	70152			
EVT_CONTROL_STAND_ENG2_START_LEVER	521	70153			

Pedestal - Aft Aisle Stand - COMM Panels	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_COM1_HF_SENSOR_KNOB	525	70157			
EVT_COM1_TRANSFER_SWITCH	526	70158			
EVT_COM1_OUTER_SELECTOR	527	70159			
EVT_COM1_INNER_SELECTOR	528	70160			
EVT_COM1_VHFL_SWITCH	529	70161			
EVT_COM1_VHFC_SWITCH	530	70162			
EVT_COM1_VHFR_SWITCH	531	70163			
EVT_COM1_PNL_OFF_SWITCH	532	70164			
EVT_COM1_HFL_SWITCH	533	70165			
EVT_COM1_AM_SWITCH	534	70166			
EVT_COM1_HFR_SWITCH	535	70167			
EVT_COM2_HFR_SWITCH	792	70424			
EVT_COM2_AM_SWITCH	793	70425			
EVT_COM2_HFL_SWITCH	794	70426			
EVT_COM2_PNL_OFF_SWITCH	795	70427			
EVT_COM2_VHFR_SWITCH	796	70428			
EVT_COM2_VHFC_SWITCH	797	70429			

EVT_COM2_VHFL_SWITCH	798	70430			
EVT_COM2_INNER_SELECTOR	799	70431			
EVT_COM2_OUTER_SELECTOR	800	70432			
EVT_COM2_TRANSFER_SWITCH	801	70433			
EVT_COM2_HF_SENSOR_KNOB	802	70434			
EVT_COM3_HF_SENSOR_KNOB	596	70228			
EVT_COM3_TRANSFER_SWITCH	597	70229			
EVT_COM3_OUTER_SELECTOR	598	70230			
EVT_COM3_INNER_SELECTOR	599	70231			
EVT_COM3_VHFL_SWITCH	600	70232			
EVT_COM3_VHFC_SWITCH	601	70233			
EVT_COM3_VHFR_SWITCH	602	70234			
EVT_COM3_PNL_OFF_SWITCH	603	70235			
EVT_COM3_HFL_SWITCH	604	70236			
EVT_COM3_AM_SWITCH	605	70237			
EVT_COM3_HFR_SWITCH	606	70238			

Pedestal - Aft Aisle Stand - ACP Captain	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_ACP_CAPT_MIC_VHFL	536	70168			
EVT_ACP_CAPT_MIC_VHFC	537	70169			
EVT_ACP_CAPT_MIC_VHFR	538	70170			
EVT_ACP_CAPT_MIC_FLT	539	70171			
EVT_ACP_CAPT_MIC_CAB	540	70172			
EVT_ACP_CAPT_MIC_PA	541	70173			
EVT_ACP_CAPT_MIC_HFL	555	70187			
EVT_ACP_CAPT_MIC_HFR	556	70188			
EVT_ACP_CAPT_MIC_SAT1	557	70189			
EVT_ACP_CAPT_MIC_SAT2	558	70190			
EVT_ACP_CAPT_REC_VHFL	548	70180			
EVT_ACP_CAPT_REC_VHFC	549	70181			
EVT_ACP_CAPT_REC_VHFR	550	70182			
EVT_ACP_CAPT_REC_FLT	551	70183			
EVT_ACP_CAPT_REC_CAB	552	70184			
EVT_ACP_CAPT_REC_PA	553	70185			
EVT_ACP_CAPT_REC_HFL	565	70197			
EVT_ACP_CAPT_REC_HFR	566	70198			
EVT_ACP_CAPT_REC_SAT1	567	70199			
EVT_ACP_CAPT_REC_SAT2	568	70200			
EVT_ACP_CAPT_REC_SPKR	564	70196			
EVT_ACP_CAPT_REC_VORADF	571	70203			
EVT_ACP_CAPT_REC_APP	573	70205			
EVT_ACP_CAPT_MIC_INT_SWITCH	554	70186			
EVT_ACP_CAPT_FILTER_SELECTOR	572	70204			
EVT_ACP_CAPT_VOR_ADF_SELECTOR	569	70201			
EVT_ACP_CAPT_APP_SELECTOR	575	70207			

Pedestal - Aft Aisle Stand - ACP F/O	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_ACP_FO_MIC_VHFL	791	70423			
EVT_ACP_FO_MIC_VHFC	790	70422			
EVT_ACP_FO_MIC_VHFR	789	70421			

EVT_ACP_FO_MIC_FLT	788	70420			
EVT_ACP_FO_MIC_CAB	787	70419			
EVT_ACP_FO_MIC_PA	786	70418			
EVT_ACP_FO_MIC_HFL	772	70404			
EVT_ACP_FO_MIC_HFR	771	70403			
EVT_ACP_FO_MIC_SAT1	770	70402			
EVT_ACP_FO_MIC_SAT2	769	70401			
EVT_ACP_FO_REC_VHFL	779	70411			
EVT_ACP_FO_REC_VHFC	778	70410			
EVT_ACP_FO_REC_VHFR	777	70409			
EVT_ACP_FO_REC_FLT	776	70408			
EVT_ACP_FO_REC_CAB	775	70407			
EVT_ACP_FO_REC_PA	774	70406			
EVT_ACP_FO_REC_HFL	762	70394			
EVT_ACP_FO_REC_HFR	761	70393			
EVT_ACP_FO_REC_SAT1	760	70392			
EVT_ACP_FO_REC_SAT2	759	70391			
EVT_ACP_FO_REC_SPKR	763	70395			
EVT_ACP_FO_REC_VORADF	756	70388			
EVT_ACP_FO_REC_APP	754	70386			
EVT_ACP_FO_MIC_INT_SWITCH	773	70405			
EVT_ACP_FO_FILTER_SELECTOR	755	70387			
EVT_ACP_FO_VOR_ADF_SELECTOR	758	70390			
EVT_ACP_FO_APP_SELECTOR	752	70384			

Pedestal - Aft Aisle Stand - ACP Observer	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_ACP_OBS_MIC_VHFL	607	70239			
EVT_ACP_OBS_MIC_VHFC	608	70240			
EVT_ACP_OBS_MIC_VHFR	609	70241			
EVT_ACP_OBS_MIC_FLT	610	70242			
EVT_ACP_OBS_MIC_CAB	611	70243			
EVT_ACP_OBS_MIC_PA	612	70244			
EVT_ACP_OBS_MIC_HFL	626	70258			
EVT_ACP_OBS_MIC_HFR	627	70259			
EVT_ACP_OBS_MIC_SAT1	628	70260			
EVT_ACP_OBS_MIC_SAT2	629	70261			
EVT_ACP_OBS_REC_VHFL	619	70251			
EVT_ACP_OBS_REC_VHFC	620	70252			
EVT_ACP_OBS_REC_VHFR	621	70253			
EVT_ACP_OBS_REC_FLT	622	70254			
EVT_ACP_OBS_REC_CAB	623	70255			
EVT_ACP_OBS_REC_PA	624	70256			
EVT_ACP_OBS_REC_HFL	636	70268			
EVT_ACP_OBS_REC_HFR	637	70269			
EVT_ACP_OBS_REC_SAT1	638	70270			
EVT_ACP_OBS_REC_SAT2	639	70271			
EVT_ACP_OBS_REC_SPKR	635	70267			
EVT_ACP_OBS_REC_VORADF	642	70274			
EVT_ACP_OBS_REC_APP	644	70276			
EVT_ACP_OBS_MIC_INT_SWITCH	625	70257			

EVT_ACP_OBS_FILTER_SELECTOR	643	70275			
EVT_ACP_OBS_VOR_ADF_SELECTOR	640	70272			
EVT_ACP_OBS_APP_SELECTOR	646	70278			

Pedestal - Aft Aisle Stand - WX RADAR panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_WXR_L_TFR	576	70208			
EVT_WXR_L_WX	577	70209			
EVT_WXR_L_WX_T	578	70210			
EVT_WXR_L_MAP	579	70211			
EVT_WXR_L_GC	580	70212			
EVT_WXR_AUTO	583	70215			
EVT_WXR_L_R	584	70216			
EVT_WXR_TEST	585	70217			
EVT_WXR_R_TFR	588	70220			
EVT_WXR_R_WX	589	70221			
EVT_WXR_R_WX_T	590	70222			
EVT_WXR_R_MAP	591	70223			
EVT_WXR_R_GC	592	70224			
EVT_WXR_L_TILT_CONTROL	581	70213			
EVT_WXR_L_GAIN_CONTROL	582	70214			
EVT_WXR_R_TILT_CONTROL	586	70218			
EVT_WXR_R_GAIN_CONTROL	587	70219			

Pedestal - Aft Aisle Stand - TCAS panel	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_TCAS_ALTSOURCE	743	70375			
EVT_TCAS_KNOB_L_OUTER	744	70376			
EVT_TCAS_KNOB_L_INNER	745	70377			
EVT_TCAS_IDENT	746	70378			
EVT_TCAS_KNOB_R_OUTER	747	70379			
EVT_TCAS_KNOB_R_INNER	748	70380			
EVT_TCAS_MODE	749	70381			
EVT_TCAS_TEST	7491	77123			
EVT_TCAS_XPNDR	751	70383			

Pedestal - Aft Aisle Stand - CALL Panel (Freighter only)	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_PED_CALL_GND	1078	70710			
EVT_PED_CALL_CREW_REST	1079	70711			
EVT_PED_CALL_SUPRNMRY	1080	70712			
EVT_PED_CALL_CARGO	1081	70713			
EVT_PED_CALL_CARGO_AUDIO	1082	70714			
EVT_PED_CALL_MAIN_DK_ALERT	1083	70715			

Pedestal - Aft Aisle Stand - Miscellaneous	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_PED_OBS_AUDIO_SELECTOR	648	70280			
EVT_FCTL_AILERON_TRIM	727	70359			
EVT_FCTL_RUDDER_TRIM	728	70360			
EVT_FCTL_RUDDER_TRIM_CANCEL	729	70361			
EVT_PED_FLOOR_LIGHTS	735	70367			
EVT_PED_PANEL_LIGHT_CONTROL	736	70368			
EVT_PED_FLOOD_LIGHT_CONTROL	737	70369			

EVT_PED_EVAC_SWITCH	739	70371			
EVT_PED_EVAC_SWITCH_GUARD	740	70372			
EVT_PED_EVAC_HORN_SHUTOFF	741	70373			
EVT_PED_EVAC_TEST_SWITCH	742	70374			

Pedestal - Control Stand	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_CONTROL_STAND_SPEED_BRAKE_LEVER	498	70130			
EVT_CONTROL_STAND_SPEED_BRAKE_LEVER_DOWN	4981	74613			
EVT_CONTROL_STAND_SPEED_BRAKE_LEVER_ARM	4982	74614			
EVT_CONTROL_STAND_SPEED_BRAKE_LEVER_UP	4983	74615			
EVT_CONTROL_STAND_SPEED_BRAKE_LEVER_50	4984	74616			
EVT_CONTROL_STAND_FLAPS_LEVER	507	70139			
EVT_CONTROL_STAND_FLAPS_LEVER_0	5071	74703			
EVT_CONTROL_STAND_FLAPS_LEVER_1	5072	74704			
EVT_CONTROL_STAND_FLAPS_LEVER_5	5073	74705			
EVT_CONTROL_STAND_FLAPS_LEVER_15	5074	74706			
EVT_CONTROL_STAND_FLAPS_LEVER_20	5075	74707			
EVT_CONTROL_STAND_FLAPS_LEVER_25	5076	74708			
EVT_CONTROL_STAND_FLAPS_LEVER_30	5077	74709			
EVT_CONTROL_STAND_ALT_PITCH_TRIM_LEVER	496	70128			
EVT_CONTROL_STAND_REV_THRUST1_LEVER	499	70131			
EVT_CONTROL_STAND_REV_THRUST2_LEVER	503	70135			
EVT_CONTROL_STAND_FWD_THRUST1_LEVER	501	70133			
EVT_CONTROL_STAND_FWD_THRUST2_LEVER	505	70137			
EVT_CONTROL_STAND_AT1_DISENGAGE_SWITCH	502	70134			
EVT_CONTROL_STAND_AT2_DISENGAGE_SWITCH	506	70138			
EVT_CONTROL_STAND_TOGA1_SWITCH	500	70132			
EVT_CONTROL_STAND_TOGA2_SWITCH	504	70136			
EVT_CONTROL_STAND_PARK_BRAKE_LEVER	515	70147			
EVT_CONTROL_STAND_STABCUTOUT_SWITCH_C_GUARD	516	70148			
EVT_CONTROL_STAND_STABCUTOUT_SWITCH_C	517	70149			
EVT_CONTROL_STAND_STABCUTOUT_SWITCH_R_GUARD	518	70150			
EVT_CONTROL_STAND_STABCUTOUT_SWITCH_R	519	70151			

Oxygen Panels	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_OXY_TEST_RESET_SWITCH_L	1063	70695			
EVT_OXY_TEST_RESET_SWITCH_R	1066	70698			
EVT_OXY_TEST_RESET_SWITCH_OBS_R	1069	70701			
EVT_OXY_TEST_RESET_SWITCH_OBS_L	1072	70704			
EVT_OXY_NORM_EMER_L	1064	70696			
EVT_OXY_NORM_EMER_R	1067	70699			
EVT_OXY_NORM_EMER_OBS_R	1070	70702			
EVT_OXY_NORM_EMER_OBS_L	1073	70705			

Miscellaneous	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_YOKE_AP_DISC_SWITCH	1084	70716			
EVT_CLICKSPOT_ISFD	1101	70733			
EVT_CLICKSPOT_STBY_ADI	1102	70734			
EVT_CLICKSPOT_STBY_ASI	1103	70735			
EVT_CLICKSPOT_STBY_ALTIMETER	1104	70736			

EVT_CLICKSPOT_GMCS_ZOOM	1112	70744			
-------------------------	------	-------	--	--	--

Custom shortcut special events	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_LDG_LIGHTS_TOGGLE	14000	83632			
EVT_TURNOFF_LIGHTS_TOGGLE	14001	83633			
EVT_COCKPIT_LIGHTS_TOGGLE	14002	83634			
EVT_PANEL_LIGHTS_TOGGLE	14003	83635			
EVT_FLOOD_LIGHTS_TOGGLE	14004	83636			
EVT_DOOR_1L	14011	83643			
EVT_DOOR_1R	14012	83644			
EVT_DOOR_2L	14013	83645			
EVT_DOOR_2R	14014	83646			
EVT_DOOR_3L	14015	83647			
EVT_DOOR_3R	14016	83648			
EVT_DOOR_4L	14017	83649			
EVT_DOOR_4R	14018	83650			
EVT_DOOR_OVERWING_EXIT_L	14019	83651			
EVT_DOOR_OVERWING_EXIT_R	14020	83652			
EVT_DOOR_CARGO_FWD	14021	83653			
EVT_DOOR_CARGO_AFT	14022	83654			
EVT_DOOR_CARGO_BULK	14023	83655			
EVT_DOOR_CARGO_MAIN	14024	83656			
EVT_DOOR_FWD_ACCESS	14025	83657			
EVT_DOOR_EE_ACCESS	14026	83658			
EVT_AT_ARM_SWITCHES	14027	83659			

MCP Direct Control	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_MCP_IAS_SET (*1)	14502	84134			
EVT_MCP_MACH_SET (*2)	14503	84135			
EVT_MCP_HDGTRK_SET (*3)	14504	84136			
EVT_MCP_ALT_SET	14505	84137			
EVT_MCP_VS_SET (*4)	14506	84138			
EVT_MCP_FPA_SET (*5)	14507	84139			

Panel system events	SDK Value	EVENT ID	Parameter	MODULE	SW/PIN
EVT_CTRL_ACCELERATION_DISABLE	14600	84232			
EVT_CTRL_ACCELERATION_ENABLE	14600	84232			
EVT_2D_PANEL_OFFSET (*6)	20000	89632			

(*1) Sets MCP IAS, if IAS mode is active

(*2) Sets MCP MACH (if active to parameter*0.01 (e.g. send 78 to set M0.78))

(*3) Sets new heading or track, commands the shortest turn

(*4) Sets MCP VS (if VS window open to parameter-10000 (e.g. send 8200 for -1800fpm))

(*5) Sets MCP FPA (if VS window open to parameter*0.1-10 (e.g. send 82 for -1.8 degrees))

(*6) added to events trigger by 2D panel pop-up windows

*** a registered copy of Pete Dowson's FSUIPC is required!**

Mouse flags for mouse simulated events

Mouse Action to assign	Parameter
MOUSE_FLAG_RIGHTSINGLE	2147483648
MOUSE_FLAG_MIDDLE SINGLE	1073741824
MOUSE_FLAG_LEFTSINGLE	536870912
MOUSE_FLAG_RIGHTDOUBLE	268435456
MOUSE_FLAG_MIDDLEDDOUBLE	134217728
MOUSE_FLAG_LEFTDOUBLE	67108864
MOUSE_FLAG_RIGHTDRAG	33554432
MOUSE_FLAG_MIDDLEDRAG	16777216
MOUSE_FLAG_LEFTDRAG	8388608
MOUSE_FLAG_MOVE	4194304
MOUSE_FLAG_DOWN_REPEAT	2097152
MOUSE_FLAG_RIGHTRELEASE	524288
MOUSE_FLAG_MIDDLERELEASE	262144
MOUSE_FLAG_LEFTRELEASE	131072
MOUSE_FLAG_WHEEL_FLIP (invert direction of mouse wheel)	65563
MOUSE_FLAG_WHEEL_SKIP(look at next 2 rect for mouse wheel commands)	32768
MOUSE_FLAG_WHEEL_UP 16384	16384
MOUSE_FLAG_WHEEL_DOWN	8192

